

INSTRUCTIONS

Self Inflatable Mats

TO INFLATE

- Turn the valve(s) counter-clockwise to the open position.
- Holding the mat with both hands at the valve end, shake the mat several times to unroll and eliminate folds.
- Note, on first use you may have to inflate and deflate the mat on 2 or 3 occasions to achieve optimum inflation speed.
- When the mat has inflated turn the valve(s) clockwise to the locked position, taking care not to over-tighten.
- To obtain extra firmness additional air can be added by blowing through one opened valve, remembering to turn the valve to the locked position on completion.

TO DEFLATE

- Turn the valve(s) counter-clockwise to the open position.
- Roll from the end opposite the valve(s) applying gentle pressure and allowing the air to escape quickly.
- When deflated, turn the valve(s) clockwise to the locked position. For a more compact size, unroll the mat with the valve(s) still in the locked position and re-roll. This will cause the remaining air to be pushed towards the valve(s). Then, turn the valve(s) counter-clockwise to the open position to release the remaining air. Turn the valve(s) to the locked position when finished.

Inflatable Mats

TO INFLATE

- Holding the mat with both hands at the valve end, shake the mat several times to unroll and eliminate folds.
- Inflate by mouth to desired level of firmness.
- When the mat has been inflated, turn the valve(s) clockwise. You will feel a resistance as the valve reaches the locked position and the cap will remain in position when released. Take care not to over-tighten the valve.

TO DEFLATE

- Turn the valve counter-clockwise to the open position.
- Roll from the end opposite the valve applying gentle pressure to allow the air to escape more quickly.

CARE & REPAIR

Repair

NOTE:

The contact adhesive is NOT INCLUDED. Due to shipping regulations we are unable to include the glue in the repair kit. You will need to buy a small tube of repair glue, which can be purchased at most hardware or outdoor stores.

To repair, locate punctures. Inflate the mattress, close the valve(s) and submerge mattress in a bath of water while applying pressure by partially rolling or folding the mattress. Escaping air bubbles will indicate the position of the puncture. Mark it, and dry the mattress.

FOR SMALL PUNCTURES:

1. Apply a drop of adhesive to the puncture.
2. Allow to fully dry, then submerge the mattress, applying gentle pressure and check that air bubbles are no longer escaping.

FOR LARGE CUTS AND TEARS:

1. Clean the surface around the cut/tear.
2. Spread a contact adhesive onto the cut or tear.
3. Apply adhesive on to the repair patch.
4. For waiting times - follow the adhesive instructions.
5. Apply the patch on to the cut or tear ensuring it is completely covered & maintain pressure.
6. Allow adhesive to set in accordance with the instructions before inspection.

Washing & Cleaning

Use soapy water and rinse with clean water, then dry fully before storage.

Storage

Prior to storage please ensure that the mat is completely dry. Failure to do so can result in excessive dampness leading to mildew, which can damage the fabric.

It is important to store the mattress unrolled in a cool, dry place with the valve(s) in the open position. This will lead to faster self-inflation next time the mat is used and longer life.

Caution

Carelessness causes fire - do not expose to naked flame.

Do not expose to prolonged UV radiation.

Open valves when leaving in an unventilated place so expanding air can escape if the temperature increases.

12 MONTH GUARANTEE

Details of Guarantee

This product is covered by a 12-month guarantee from the date of purchase.

This guarantee covers manufacturing defects in materials and workmanship.

It does not cover punctures, normal wear and tear, abrasion, misuse, alteration, or improper care including: incorrect washing and drying, accidental damage, prolonged UV exposure or the natural breakdown of certain materials over a long period of time.

In the unlikely event that a fault does occur then please contact our Customer Services Department by visiting www.multimatusa.com or by using the contact details provided. Proof of purchase will be required to validate a claim under this guarantee.

This guarantee does not affect your statutory rights.

PROFORCE EQUIPMENT, INC.
3230 Executive Way
Miramar, FL 33025

Phone: 305-436-7984
Fax: 305-436-7985

www.multimatusa.com

multimat[®]
be comfortable sleep warm

Instructions ●

Care & Repair ●

12 Month Guarantee ●

www.multimatusa.com